



# POWER PACK REPLACEMENT KIT

FOR INTELLICHLOR® LT15 SALT CHLORINE GENERATORS

This document provides install instructions for the IntelliChlor LT15 Salt Chlorine Generator (SCG) power pack. Follow the instructions below to ensure proper installation.

For additional IntelliChlor LT and IntelliChlor Plus instructions or resources, scan the QR code or visit [www.pentair.com](http://www.pentair.com).



**IMPORTANT SAFETY INSTRUCTIONS** - When installing and using this electrical equipment, basic safety precautions should always be followed, including the following:

## READ AND FOLLOW ALL INSTRUCTIONS


## SAVE THESE INSTRUCTIONS

**WARNING** To reduce the risk of injury, do not permit children to use this product unless they are closely supervised at all times.

**CAUTION** ONLY connect the IntelliChlor LT15 to an approved LT15 Power Pack (P/N 523753) or PC100 Power Center. Operating the LT15 with older IntelliChlor or iChlor power packs will permanently damage the cell electronics.

**CAUTION** Disconnect main power to the power pack before disconnecting or connecting the SCG cell.

1. Unplug the existing power pack.
2. Disconnect the SCG cell from the existing power pack.
3. If mounted, unmount the power pack and discard.
4. If mounting the new power pack, mount to a vertical surface within 15 ft. [4.6 m] of the SCG cell.
5. Align the Cell Cable Connector with the Power Pack Connector (**Figure 1**) and insert the cell cable.
6. Firmly fasten the cell cable to the power pack.
7. Plug the power pack into the desired outlet.



**FIGURE 1**

# TROUSSE DE RECHANGE DU BLOC D'ALIMENTATION

## POUR CHLORATEURS AU SEL INTELЛИCHLOR® LT15

Ce document fournit des instructions d'installation pour le bloc d'alimentation du chlorateur au sel (CS) IntelliChlor LT et IntelliChlor Plus. Suivez les instructions ci-dessous pour garantir une installation correcte.

Pour obtenir des instructions ou des ressources supplémentaires sur IntelliChlor LT et IntelliChlor Plus, scannez le code QR ou visitez [www.pentair.com](http://www.pentair.com).



**CONSIGNES DE SÉCURITÉ IMPORTANTES** - Lors de l'installation et de l'utilisation de cet équipement électrique, des précautions de sécurité de base doivent toujours être respectées, notamment les suivantes :

### LISEZ ET SUIVEZ TOUTES LES INSTRUCTIONS / CONSERVEZ CES INSTRUCTIONS

**⚠ MISE EN GARDE** Pour réduire le risque de blessure, ne laissez pas les enfants utiliser ce produit à moins qu'ils ne soient étroitement surveillés à tout moment.

**⚠ ATTENTION** Raccorder UNIQUEMENT l'IntelliChlor LT15 à un bloc d'alimentation LT15 approuvé (numéro de pièce 523753) ou à un centre électrique PC100. L'utilisation du LT15 avec les anciens blocs d'alimentation IntelliChlor ou iChlor endommagera définitivement les composants électroniques de la cellule.

**⚠ ATTENTION** Débrancher l'alimentation principale du bloc d'alimentation avant de débrancher ou de raccorder la cellule du CS.

1. Débranchez le bloc d'alimentation existant.
2. Déconnectez la cellule CS du bloc d'alimentation existant.
3. Si elle est montée, démontez le bloc d'alimentation et jetez-le.
4. Si vous montez le nouveau bloc d'alimentation, montez-le sur une surface verticale à moins de 4,6 m [15 pi] de la cellule CS.
5. Alignez le connecteur du câble de la cellule avec le connecteur du bloc d'alimentation (**Figure 1**) et insérez le câble de la cellule.
6. Fixez fermement le câble de la cellule au bloc d'alimentation.
7. Branchez le bloc d'alimentation dans la prise souhaitée.




FIGURE 1