



INTELLIFL03® VSF INTELLIPR03® VSF

VARIABLE SPEED AND FLOW PUMPS

INSTALLATION AND MAINTENANCE GUIDE

IMPORTANT SAFETY INSTRUCTIONS
READ AND FOLLOW ALL INSTRUCTIONS
SAVE THESE INSTRUCTIONS

To access digital copies of all IntelliFlo3 VSF manuals, scan or click the provided QR code.

Para acceder a copias digitales de todos los manuales de IntelliFlo3 VSF, escanee o haga clic en el código QR proporcionado.

Pour accéder aux copies numériques de tous les manuels IntelliFlo3 VSF, scannez ou cliquez sur le code QR fourni.



IMPORTANT SAFETY INSTRUCTIONS



This guide provides important installation, operation and maintenance instructions related to this equipment. Consult Pentair or a qualified pool professional with any questions.

Attention Installer: This guide contains important information that helps ensure proper and safe installation, operation and maintenance of this equipment. Ensure this guide is given to the pool owner and/or operator of this equipment after installation.

Attention User: This guide contains important information that helps ensure proper and safe operation and maintenance of this equipment. Retain this quide for future reference.

Call (800) 831-7133 for additional free copies of these instructions or product labels. Refer to www.pentair.com for more information.

READ AND FOLLOW ALL INSTRUCTIONS SAVE THESE INSTRUCTIONS



This is the safety alert symbol. When you see this symbol in this guide or on the product itself, look for one of the following signal words and be aware of the potential for personal injury.



Warns of hazards that may cause death, serious personal injury, or major property damage if ignored.



Warns of hazards that may cause serious personal injury or major property damage if ignored.



Warns of hazards that may or can cause minor personal injury or property damage if ignored.

Carefully read and follow all instructions in this guide or displayed on the equipment. Ensure all product labels are kept in good condition and replace missing or damaged labels immediately.

FAILURE TO FOLLOW ALL INSTRUCTIONS AND A DANGER WARNINGS CAN RESULT IN SERIOUS BODILY

INJURY OR DEATH. THIS PUMP SHOULD BE INSTALLED AND SERVICED ONLY BY A QUALIFIED POOL SERVICE PROFESSIONAL. INSTALLERS, POOL OPERATORS AND OWNERS MUST READ THESE WARNINGS AND ALL INSTRUCTIONS IN THE OWNER'S MANUAL BEFORE USING THIS PUMP. THESE WARNINGS AND THE OWNER'S MANUAL MUST BE LEFT WITH THE POOL OWNER.

AWARNING Do not permit children to use this product.

RISK OF ELECTRICAL SHOCK. Connect only to a warning branch circuit protected by a ground-fault circuit-

interrupter (GFCI). Contact a qualified electrician if you cannot verify that the circuit is protected by a GFCI.

WARNING This unit must be connected only to a supply circuit that is protected by a ground-fault circuit-interrupter (GFCI). Such a GFCI should be provided by the installer and should be tested on a routine basis. To test the GFCI, push the test button. The GFCI should interrupt power. Push the reset button. Power should be restored. If the GFCI fails to operate in this manner, the GFCI is defective. If the GFCI interrupts power to the pump without the test button being pushed, a ground current is flowing, indicating the possibility of an electric shock. Do not use this pump. Disconnect the pump and have the problem corrected by a qualified service representative before using

This pump is for use with permanent swimming pools **ACAUTION** and may also be used with hot tubs and spas if so marked. Do not use with storable pools. A permanently-installed pool is constructed in or on the ground or in a building such that it cannot be readily disassembled for storage. A storable pool is constructed so that it is capable of being readily disassembled for storage and reassembled to its original integrity.

General Warnings

- Never open the inside of the drive motor enclosure. There is a capacitor bank that holds a 230 VAC charge even when there is no power to the
- · The pump is not submersible.
- · The pump is capable of high flow rates; use caution when installing and programming to limit performance potential with old or questionable
- · Code requirements for electrical connection differ from country to country, state to state, as well as local municipalities. Install equipment in accordance with the National Electrical Code and all applicable local codes and ordinances.
- Before servicing the pump, switch OFF power to the pump by disconnecting the main circuit to the pump.
- This appliance is not intended for use by persons (including children) of reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning the use of the appliance by a person responsible for their safety.

⚠ DANGER

SUCTION ENTRAPMENT HAZARD: STAY OFF THE MAIN DRAIN AND AWAY FROM ALL SUCTION

OUTLETS! THIS PUMP IS NOT EQUIPPED WITH SAFETY VACUUM RELEASE SYSTEM (SVRS) PROTECTION AND DOES NOT PROTECT AGAINST BODY OR LIMB ENTRAPMENTS, DISEMBOWELMENTS (WHEN A PERSON SITS ON A BROKEN OR UNCOVERED POOL DRAIN) OR HAIR ENTANGLEMENTS.











THIS PUMP PRODUCES HIGH LEVELS OF SUCTION AND CREATES A STRONG VACUUM AT THE MAIN DRAIN AT THE BOTTOM OF THE BODY OF WATER, THIS SUCTION IS SO STRONG THAT IT CAN TRAP ADULTS OR CHILDREN UNDER WATER IF THEY COME IN CLOSE PROXIMITY TO A DRAIN OR A LOOSE OR BROKEN DRAIN COVER OR GRATE.

THE USE OF UNAPPROVED COVERS OR ALLOWING USE OF THE POOL OR SPA WHEN COVERS ARE MISSING, CRACKED OR BROKEN CAN RESULT IN BODY OR LIMB ENTRAPMENT, HAIR ENTANGLEMENT, BODY ENTRAPMENT. EVISCERATION AND/OR DEATH.

The suction at a drain or outlet can cause:

Limb Entrapment: When a limb is sucked or inserted into an opening resulting in a mechanical bind or swelling. This hazard is present when a drain cover is missing, broken, loose, cracked or not properly secured.

Hair Entanglement: When the hair tangles or knots in the drain cover, trapping the swimmer underwater. This hazard is present when the flow rating of the cover is too small for the pump or pumps.

Body Entrapment: When a portion of the body is held against the drain cover trapping the swimmer underwater. This hazard is present when the drain cover is missing, broken or the cover flow rating is not high enough for the pump or pumps.

Evisceration/Disembowelment: When a person sits on an open pool (particularly a child wading pool) or spa outlet and suction is applied directly to the intestines, causing severe intestinal damage. This hazard is present when the drain cover is missing, loose, cracked, or not properly secured.

Mechanical Entrapment: When jewelry, swimsuit, hair decorations, finger, toe or knuckle is caught in an opening of an outlet or drain cover. This hazard is present when the drain cover is missing, broken, loose, cracked, or not properly secured.

NOTE: ALL SUCTION PLUMBING MUST BE INSTALLED IN ACCORDANCE WITH THE LATEST NATIONAL AND LOCAL CODES, STANDARDS AND GUIDELINES.

IMPORTANT SAFETY INSTRUCTIONS

▲ WARNING

TO MINIMIZE THE RISK OF INJURY DUE TO SUCTION ENTRAPMENT HAZARD:

- A properly installed and secured ANSI/ASME A112.19.8 approved antientrapment suction cover must be used for each drain.
- Each suction cover must be installed at least 3 ft (0.9 m) apart, as measured from the nearest point to nearest point.
- Regularly inspect all covers for cracks, damage and advanced weathering.
- If a cover becomes loose, cracked, damaged, broken or is missing, replace with an appropriate certified cover.
- Replace drain covers as necessary. Drain covers deteriorate over time due to exposure to sunlight and weather.
- Avoid getting hair, limbs or body in close proximity to any suction cover. pool drain or outlet.
- Disable suction outlets or reconfigure into return inlets.

▲ WARNING

The pump can produce high levels of suction within the suction side of the plumbing system. These high levels

of suction can pose a risk if a person comes within close proximity of the suction openings. A person can be seriously injured by this high level of vacuum or may become trapped and drown. It is absolutely critical that the suction plumbing be installed in accordance with the latest national and local codes for swimming pools.

A clearly labeled emergency shut-off switch for the pump MARNING must be in an easily accessible, obvious place. Make

sure users know where it is and how to use it in case of emergency.

The Virginia Graeme Baker (VGB) Pool and Spa Safety Act creates new requirements for owners and operators of commercial swimming pools and spas.

Commercial pools or spas constructed on or after December 19, 2008, shall utilize:

(A) A multiple main drain system without isolation capability with suction outlet covers that meet ASME/ANSI A112.19.8a Suction Fittings for Use in Swimming Pools, Wading Pools, Spas, and Hot Tubs and either:

- (i) A safety vacuum release system (SVRS) meeting ASME/ANSI A112.19.17 Manufactured Safety Vacuum Release Systems (SVRS) for Residential and Commercial Swimming Pool, Spa, Hot Tub, and Wading Pool Suction Systems and/or ASTM F2387 Standard Specification for Manufactured Safety Vacuum Release Systems (SVRS) for Swimming pools, Spas and Hot Tubs or
- (ii) A properly designed and tested suction-limiting vent system or
- (iii) An automatic pump shut-off system.

Commercial pools and spas constructed prior to December 19, 2008, with a single submerged suction outlet shall use a suction outlet cover that meets ASME/ANSI A112.19.8a and either:

- (A) A SVRS meeting ASME/ANSI A112.19.17 and/or ASTM F2387, or
- (B) A properly designed and tested suction-limiting vent system, or
- (C) An automatic pump shut-off system, or
- (D) Disabled submerged outlets, or
- (E) Suction outlets shall be reconfigured into return inlets.

ACAUTION

For Installation of Electrical Controls at Equipment Pad (ON/OFF Switches, Timers and Automation Load Center)



Install all electrical controls at equipment pad, such as on/off switches, timers, and control systems, etc. to allow the operation (startup, shut-down, or servicing) of any pump or filter so the user does not place any portion

of his/her body over or near the pump strainer lid, filter lid or valve closures. This installation should allow the user enough space to stand clear of the filter and pump during system start-up, shut down or servicing of the system filter.

⚠ DANGER

HAZARDOUS PRESSURE: STAND CLEAR OF PUMP AND FILTER DURING START UP.



Circulation systems operate under high pressure. When any part of the circulating system (i.e. locking ring, pump, filter, valves, etc.) is serviced, air can enter the system and become pressurized. Pressurized air can cause the pump housing cover, filter lid, and valves to violently separate which can result in severe personal injury or death. Filter tank lid and strainer cover must be

properly secured to prevent violent separation. Stand clear of all circulation system equipment when turning on or starting up pump.

Before servicing equipment, make note of the filter pressure. Be sure that all controls are set to ensure the system cannot inadvertently start during service. Turn off all power to the pump. IMPORTANT: Place filter manual air relief valve in the open position and stand clear of the filter until all pressure has been relieved and the pressure gauge reads 0 psi.

Before starting the system, fully open the manual air relief valve and place all system valves in the "open" position to allow water to flow freely from the tank and back to the tank. Stand clear of all equipment and start the pump.

IMPORTANT: Do not close filter manual air relief valve until all pressure has been discharged from the valve and a steady stream of water appears. Observe filter pressure gauge and be sure it is not higher than the pre-service condition.

General Installation Information

- · All work must be performed by a qualified service professional, and must conform to all national, state, and local codes.
- Install to provide drainage of compartment for electrical components.
- These instructions contain information for a variety of pump models and therefore some instructions may not apply to a specific model. All models are intended for use in swimming pool applications. The pump will function correctly only if it is properly sized to the specific application and properly installed.

▲ WARNING

Pumps improperly sized or installed or used in applications other than for which the pump was

intended can result in severe personal injury or death. These risks may include but not be limited to electric shock, fire, flooding, suction entrapment or severe injury or property damage caused by a structural failure of the pump or other system component.

Pumps and replacement motors that are single speed and one (1) Total HP or greater cannot be sold, offered for sale, or installed in a residential pool for filtration use in California, Title 20 CCR sections 1601-1609.

CUSTOMER SERVICE / TECHNICAL SUPPORT

Hours: 9:00am to 7:00pm EST (6:00am - 4:00pm PST)

Call: (800) 831-7133 Visit: www.pentair.com Fax: (800) 284-4151

TABLE OF CONTENTS

IMPORTANT SAFETY INSTRUCTIONSOVERVIEW		MAINTENANCE	15
Available Accessories Motor Features Drive Features Flexible Demand Features	1 1 1	Winterizing SERVICING Motor and Drive Care Disassembly Reassembly	15 16 16 17
INSTALLATION Location Plumbing and Fittings Valves	2 2 3 3	Pump Disassembly/Reassembly Diagram Drive Removal and Installation Relocating the WiFi Antenna	18 19 19
Electrical Installation Electrical Specifications Wiring Grounding	4 4 4 4	TROUBLESHOOTING Drive LED Indicators Troubleshooting Chart Alarms and Warnings	20 20 20 23
Bonding Connecting to an Automation System Relay Control Board Digital Inputs	4 5 6	REPLACEMENT PARTS	24 25 25
OPERATION Drive Controls/Buttons Priming the Pump Default Settings Restore System Defaults Factory Reset Pentair Pool App Operation Touchscreen Operation Pump Dashboard Program Setup Device Settings Relay Settings Priming Parameters Limits Parameters Touchscreen Menu Tree	7 7 7 8 8 8 9 9 9 10 11 12 12 13 14	1.5 HP Pumps Technical Specifications Pump Dimensions Pump Performance Curves 3 HP Pumps Technical Specifications Pump Dimensions Pump Dimensions Pump Performance Curves	26 26 26 26 27 27 27 27

Your feedback could play an important role in Pentair's goal to continuously improve our instructional material, and better support those who install, maintain, and use our products everyday.



Scan or click the QR code to take a quick survey and help us provide the most easy-to-use and accurate product manuals possible!

GENERAL INFORMATION

IntelliFlo3 VSF and IntelliPro3 VSF Variable Speed and Flow Pumps can be programmed to run at speeds or constant flow rates over set periods of time. This provides maximum operating efficiency and energy conservation for a variety of inground pools.

- The pump can operate at a percentage of maximum motor speed, or can be set to control its own speed and maintain a constant flow rate.
- Simply set a pump Flow Program to the desired flow rate, and the pump automatically adjusts to maintain the programmed flow rate. Programs can be set between 20-90 GPM (1.5 HP models) or 20-140 GPM (3 HP models).
- Up to 8 customizable programs that can be set for constant flow or speed in either Manual, Timer or Schedule modes.
- Programmable priming cycle with automatic detection of prime for easy start-up and automatic detection of loss of prime.
- Compatible with most cleaning systems, filters, and jet action spas.

Available Accessories

- Drive-mounted Touchscreen Controller (P/N 356159z - Almond, P/N 356348z - Black)
- Relay Control Board Kit (P/N 356365z)
- 3" Union Kit for 3 HP Pumps (P/N 410029)
- Retrofit Riser Base Kits (refer to table below for purchasable P/Ns)

Model	Replacing	Kit P/N
	IntelliFlo	357831z
	WhisperFlo	357831z
1.5 HP	IntelliPro	357832z
	Max-E-Pro	357832z
	Challenger	357832z
	IntelliPro	357833z
3 HP	Max-E-Pro	357833z
	Challenger	357833z

Motor Features

- Permanent-magnet, totally enclosed fan-cooled (TEFC) motor.
- Exceeds all Department of Energy and Energy Star requirements.
- Operates at lower temperatures due to high efficiency
- · Designed to withstand outdoor environment
- · Low noise
- **WEF**: 7.1 **THP**: 3.0 (3 HP models) **WEF**: 9.4 **THP**: 1.5 (1.5 HP models)

Drive Features

The pump drive is designed to produce maximum motor operational efficiency. The drive controls the motor's rotational speed by controlling the frequency of the supplied current. It also protects the motor and pump from operating outside of their intended operating parameters.

- WiFi and Bluetooth® Wireless Technology Connectivity
- Pentair Pool App Compatibility
- Flow based programming for precise and continuous control of pump output
- RS-485 Digital Automation Connection
- · Dry Startup Detection
- · Loss of Prime Detection
- · Smart Priming Control

Flexible Demand Features

IntelliFlo3 VSF and IntelliPro3 VSF pumps include Flexible Demand features offering an opportunity, only with the user's consent, for the user to participate in energy provider incentive programs to offset pump energy usage.

Participating in one of these programs may provide an incentive to the user, such as a monetary reward or electrical bill credit.

When enrolled in one of these programs, these features allow the energy provider (or other entities authorized by the user) the ability to automatically schedule, shift, or even curtail the pump's energy consumption during times when electricity is more expensive, the electrical grid is stressed, and/or when there is an abundance of renewable energy on the grid.

Following one of these scenarios, the pump will then adjust its operation to maintain proper filtration and chemical dispersion.

To learn more about Flexible Demand features and how to enroll, scan or press the provided QR code.



INSTALLATION

Only a qualified plumbing professional should install the pump. Refer to *IMPORTANT SAFETY INSTRUCTIONS*, *page i* for additional installation and safety information.

ACAUTION




For Installation of Electrical Controls at Equipment Pad (ON/OFF Switches, Timers and Automation Load Center) Install all electrical controls at equipment pad, such as on/off switches, timers, and control systems, etc., to allow the operation (startup, shut-down, or servicing) of any pump or filter so the user does not place any portion of his/her body over or near the pump strainer lid, filter lid or valve closures. This installation should allow the user enough space to stand clear of the filter and pump during system start-up, shut down or servicing of the system filter.


Note: The pump should not be connected in series with other pumps.

Location

Be sure the pump location meets the following requirements:

- 1. Install the pump a minimum of 5 ft (1.5 m) from the inside wall of the pool. Canadian installations require a minimum of 9.8 ft (3 m) from the inside wall of the pool.
- Install the pump a minimum of 3 ft (0.9 m) from a heater outlet.
- 3. Do not install the pump more than 10 ft (3.1 m) above the pool water level.
- 4. Provide at least 3-inch (7.6 cm) of side and rear clearance for motor disassembly and removal.
- 5. Provide at least 6-inch (15.2 cm) of vertical clearance above the for drive disassembly and removal.
- 6. Install the pump in a well ventilated location protected from excessive moisture, dirt and heat (i.e., rain gutter downspouts, sprinklers, etc.)
- 7. Secure the pump to the equipment pad at the two anchor points located under the pump volute. Anchor points are sized for up to 3/8-inch concrete anchors.
- Do NOT install this pump within an outer enclosure or beneath the skirt of a hot tub or spa unless marked accordingly.






Plumbing and Fittings


- 1. Provided union kit allows for easy plumbing to a variety of pipe diameters. Refer to *UNION KIT OPTIONS*.
- 2. For improved plumbing a larger pipe size should be used.
- To reduce friction loss and improve efficiency, short and direct suction and return lines are best.
- 4. Suction line diameter should be the same or larger than the return line diameter.
- 5. Do not install 90° elbows directly into the pump inlet or outlet.
- 6. Valves, elbows or tees installed in the suction line should be no less than five times the suction pipe diameter from the pump inlet. Refer to SUCTION PLUMBING REQUIREMENTS.

Example: A 2-inch pipe requires a 10 inches (25.4 cm) of straight run from the suction inlet. This will help the pump prime faster and last longer.



Valves

- Flooded suction systems should have valves installed in both the pump suction and return lines. This allows the pump to be isolated during routine maintenance.
- 2. Install a check valve in the return line when using this pump for any application where there is significant height to the plumbing after the pump.
- 3. Install check valves when plumbing in parallel with another pump. This helps prevent reverse rotation of the impeller and motor.



Electrical Installation



RISK OF ELECTRICAL SHOCK OR ELECTROCUTION. This pump must be installed by a licensed or certified electrician or a qualified service professional in accordance with the National Electrical Code and all applicable local codes and ordinances. Improper installation will create an electrical hazard which could result in death or serious injury to users, installers, or others due to electrical shock, and may also cause damage to property.

Always disconnect power to the pump at the circuit breaker before servicing the pump. Failure to do so could result in death or serious injury to service people, users or others due to electric shock.

Read all servicing instructions before working on the pump.

Note: ALWAYS reinstall the wiring cover onto the field wiring compartment when leaving the pump unsupervised. This will prevent foreign matter (i.e. water, dust, etc.) from accumulating in the drive.

Note: When connecting the pump to an automation system, continuous power must be supplied to the pump by connecting it directly to the circuit breaker. When using an automation system, be sure that no other lights or appliances are on the same circuit.

Electrical Specifications

Model	Voltage (VAC)	Max Amps	Input (Hz)
1.5 HP	115/208-230	12/6.4-5.9	50/60
3 HP	208-230	12.4-11.2	50/60

Circuit Protection: Require GFCI protection device, in accordance with all national and local electrical codes. The drive will operate on 2-Phase Line-Line-Ground, as well as Line-Neutral-Ground electrical systems.

Wiring

 Ensure all appropriate electrical breakers and switches are turned off before wiring the motor.



STORED CHARGE - Wait at least sixty (60) seconds before servicing.

- Ensure the supply meets the requirements listed on the motor nameplate. If these requirements are not met, permanent motor damage may occur.
- 3. The pump should be permanently connected to its own independent GFCI-protected circuit.

Note: Pentair offers 2-Pole 20 Amp GFCI breakers (P/N PA220GF) which offer personnel protection while meeting 2008 to current NEC Standards for Pool Pumps.

Note: If using a two-pole relay or timer, apply and remove power to both POWER LINE TERMINALS.

- For wiring sizes and general electrical guidelines, please follow the specifications defined in the National Electric Code and any local codes as required.
- 5. Use strain reliefs and ensure all electrical connections are clean and tight.

Note: Any unused conduit openings should be sealed with the provided conduit plugs.

Cut all wires and conductors to appropriate lengths to help prevent conductors from arcing or overlapping once connected.


Grounding

 Permanently ground the drive using the green Ground Wire Screw and ensure the ground wire is connected to an electrical service ground.

Bonding

- Bond the motor to the structure in accordance with the National Electrical Code.
- Use a solid copper bonding conductor not smaller than 8 AWG. For Canadian installations, a 6 AWG or larger solid copper bonding conductor is required.
- 3. Run a wire from the bonding lug, found on the side of the motor, to the bonding structure.

 Connect the wire to all metal parts of the pool, electrical equipment, metal conduit, and metal piping within 5 ft. (1.5 m) of the inside walls of the pool.




Connecting to an Automation System


All IntelliFlo3 VSF and IntelliPro3 VSF pumps are compatible with Pentair automation systems. Refer to the automation system manual for further details on connecting your pump to a specific automation system.

When connecting to a Pentair Automation System, connect 18 to 24 AWG, two-conductor cable to DATA+ and DATA-terminals only. If needed, 12V and Ground terminals are also provided.

WHEN THE PUMP IS CONNECTED TO AUTOMATION:

- CONNECT LED will pulse Magenta/Pink
- Touchscreen Controller (if installed) will display a message indicating the pump is being controlled by an automation system
- Pentair Pool app will display a message confirming the pump is being controlled by an automation system
- All pump control is handled by the automation system
- · When putting the automation mode into Service Mode, the automation system will return control to the pump





Relay Control Board Digital Inputs

If the optional Relay Control Board Kit (P/N 356365z) is installed, the board's digital inputs can be connected to an automation system in order to control four customizable speed or flow programs. If using digital inputs, schedules programmed via the Pentair Pool app or drive touchscreen must be deleted.

Note: If multiple external input triggers are received, programs will follow the following priority: PROGRAM 4 > 3 > 2 > 1.

Note: If the pump has been stopped via the ON/STOP button (ON/STOP LED is solid red), ON/STOP must be pressed again before the pump will operate.

When a low voltage signal is received by a control board digital input, the pump will run the program set to that specific digital input. This digital input program will override any scheduled programs, automation or manual input.

Note: Refer to the *Pentair Pool User's Guide (P/N 356088)* for instructions on viewing and editing the pump programs.

Note: Refer to the *Relay Control Board Installation Guide (P/N 356994)* for instructions on installing the control board.


The Relay Control Board also provides a +12V Output Signal (marked VOUT) that can be used to trigger its own Digital Inputs. This output signal is the recommended input for Speed Digital Inputs.

The output signal will need to be switched via an External Control (i.e. automation relay, external system component switch) to activate the desired speed program.

PROGRAM 4 > 3 > 2 > 1

Note: This VOUT output signal is output from the drive ONLY and should never be wired to a voltage supply!

DEFAULT EXTERNAL CONTROL PROGRAMS		
Program 1 40% Speed		
Program 2 60% Speed		
Program 3 80% Speed		
Program 4 100% Speed		



DIGITAL INPUTS (Low Voltage)

OPERATION

WARNING

Before starting the pump, ALWAYS follow the instructions below. Failure to follow these instructions could result in property damage and/or personal injury.

- 1. Open the filter's air relief valve.
- 2. Open all suction and return line valves.
- 3. Ensure pool return line is completely open and clear of any blockages.
- 4. Ensure the strainer pot is filled with water.
- 5. Stand clear of the filter or other pressurized vessels.

ACAUTION

Never allow the pump to run without both halves of the motor shroud installed. Operating the pump without motor shrouds installed may cause the drive to overheat and damage the drive.

Drive Controls/Buttons

Refer to Drive LED Indicators, page 20 for a list of drive LED behaviors.

CONNECT: Press to connect the pump to the Pentair Pool app. Refer to the Pentair Pool User's Guide (P/N 356088) for instructions.

ON/STOP: Press to enable or disable the pump. By default, pressing this button will either begin the priming cycle and then run the appropriate program or deactivate the pump.

If the pump is deactivated via the ON/STOP button, ON/ STOP must be pressed again before the pump will operate.

QUICK CLEAN: Press to manually start the Quick Clean program. This feature can used to temporarily override a schedule and increase pump speed while vacuuming or adding chemicals to the pool.

Once a Quick Clean cycle has ended, the pump will resume its normal schedule.

Priming the Pump

Do NOT run the pump dry. If the pump is run dry, the shaft seal will be damaged and the pump will start leaking. If this occurs, the damaged seal must be replaced.

ALWAYS maintain proper water level in your pool (half **▲** WARNING way up skimmer opening). If the water level falls below the skimmer opening, the pump will draw air through the skimmer, losing the prime and causing the pump to run dry, resulting in a damaged seal. Continued operation in this manner could cause a loss of pressure, resulting in damage to the pump case, impeller and seal and may cause property and personal injury.

This pump is shipped with Priming ENABLED. Unless the priming settings are changed, the pump will speed up to the maximum speed when the pump is powered on for the first time, and the ON/STOP button is pressed.

The pump must be filled with water and primed before initial startup and after servicing. To avoid permanent damage to the pump, follow the instructions below.


Refer to the Pentair Pool User's Guide (P/N 356088) for a list of Pentair Pool priming settings and programming instructions.

Note: If programming priming via the optional Drivemounted Touchscreen Controller, refer to Priming Parameters, page 12.

TO PRIME THE PUMP:

pot.

- 1. Press ON/STOP to stop the pump and disconnect all power to the pump at the circuit breaker.
- Close all valves in suction and return lines.
- Open the filter's air relief valve and stand clear of the filter until all pressure has been relieved and the pressure gauge reads 0 (zero) psi.
- 4. Turn the Strainer Pot Lid counter-clockwise and remove it from the pump.
- 5. Fill the strainer pot up to the Suction Port with water.
- Place the lid onto the strainer pot and tighten until the lid handles are perpendicular to the suction port. Note: Ensure the lid O-ring is properly seated and is not being pinched between the lid and strainer
- 7. Open all valves in suction and return lines.
- 8. Open the filter's air relief valve and stand clear of the filter.
- Reestablish power to the pump at the circuit breaker.
 - Continue to the next page -



ACAUTION

Do not add chemicals to the system directly in front of the pump. Adding undiluted chemicals may damage the pump and will void the warranty.

ACAUTION

This is a variable speed pump. Typically lower speeds are used for filtration and heating. Higher

speeds can be used for spa jets, water features, and priming.

Priming the Pump (continued)

- Press ON/STOP to start the pump.
 The pump will begin to prime (if enabled) and ramp up to the programmed priming speed.
- 11. When a steady stream of water appears from the air relief valve, close the valve.
- 12. Do not allow your pump to run longer than 30 minutes without successfully priming. If the pump does not prime, check your priming settings or refer to *TROUBLESHOOTING*, *page 20*.

Default Settings

If the pump is started using the ON/STOP button before a customized schedule is programmed, the pump will run the default Program 1 schedule (24 hours at 30 GPM). The Quick Clean button can be used to temporarily override this default Program 1 schedule. Default programs can be edited via the Pentair Pool app or the using the optional touchscreen.

Restore System Defaults

Restoring system defaults will delete all custom programs and restore all default settings and programs. Network settings and the security PIN (if enabled) will be retained. This can be done via the Pentair Pool app, drive controls, or optional touchscreen controller.

To restore system defaults using drive controls, disable the pump then press and hold both the CONNECT and QUICK CLEAN buttons for 3 seconds.

Factory Reset

A factory reset erases all user-entered information, including custom programs, security PIN, and network settings. All programs will be restored to factory defaults. A factory reset can only be performed using the drive controls. To perform a factory reset, disable the pump then press and hold all three buttons for 3 seconds.

Refer to the tables below for factory default settings:

PI	ROGRAMS
Program 1	Schedule Mode; 30 GPM
Program i	12 AM to 12 AM (24 Hour)
Quick Clean	Timer Mode; 70% Speed
Quick Clean	1 Hour
PRIMING	G PARAMETERS
Priming Mode	Enabled
Dry Run Detection	Enabled
Priming Speed	100%
Max Priming Duration	11 Minutes
Priming Range	5
Delay	20 Seconds
Loss of Prime Detection	Enabled
LIMITS	PARAMETERS
Min Speed	1%
Max Speed	100%
Min Flow	20 GPM
Max Flow	90 GPM (1.5 HP Pumps)
IVIAX FIOW	140 GPM (3 HP Pumps)
Flow Limit - Speed Programs	Disabled
Max Pressure	20 PSI (1.5 HP Pumps)
wax Pressure	30 PSI (3 HP Pumps)
Pressure Limit - Speed Programs	Disabled

THERMAL MODE			
Thermal Mode	Enabled		
Temp Set Point	40°F		
Pump Setting	20% Speed		
AUTOMAT	ION ADDRESS		
Pump Address	1		
EXTERNAL CONTROL PROGRAMS			
Program 1	40% Speed		
Program 2	60% Speed		
Program 3	80% Speed		
Program 4	100% Speed		
RAMP	ING SPEED		
Speed	Fast		
DEVICE	SECURITY		
Security PIN	Disabled		
C	THER		
Language	English		
Time Zone	UTC -5:00		
Daylight Savings Time	Enabled		
Units	°F / GPM / PSI		

Pentair Pool App Operation

Your IntelliFlo3 VSF or IntelliPro3 VSF pump is fully compatible with the Pentair Pool app.

The Pentair Pool app allows you to program and operate the pump from your smartphone. For instructions on how to create an app account and operate your pump via the Pentair Pool app, refer to the *Pentair Pool User's Guide (P/N 356088)* provided with your pump.

Touchscreen Operation (if installed)

If you prefer to control your pump directly from the equipment pad, a touchscreen controller allows you to adjust pump settings and program run schedules via a touchscreen mounted directly onto the pump drive. The following sections provide instructions for using your touchscreen controller.

Some pump models do not include a touchscreen controller out-of-box, but a touchscreen can be added to any IntelliFlo3 VSF or IntelliPro3 VSF pump. If you would like to add a touchscreen to your pump, Pentair offers a Touchscreen Controller Kit (Almond - P/N 356159z, Black - P/N 356348z).

Pump Dashboard

The Pump Dashboard is your pump's home screen. Basic pump info, run status and programming can be viewed from this screen.

Pump alerts or other problems will also display on this screen.

- 1- Active Alerts: Displays any active pump alerts and/or warnings.
- 2- See Running Programs: View and edit your pump's current programs. Refer to Program Setup, page 10.
- 3- Current Run Data: Displays the current pump state and program run data when the pump is running.
- **4- Relay Device Status:** Displays the status (ON/ OFF) of devices connected to the pump's 5A and/or 16A relay terminals.

Note: Relay statuses will only display if the optional Relay Control Board (P/N 356365z) is installed.

- 5- Pump Dashboard (n): Return to the Pump Dashboard (this screen) from any screen.
- 6- Alerts (△): Display active pump alerts and warnings from any screen.
 A dot to the right of the alert icon signifies an active alert or warning.
- 7- Favorite Programs (**): Display favorited programs from any screen.
 A program can be favorited by tapping the Heart icon in the top right corner of a program editing screen. Refer to Program Setup, page 10.



- 8- All Programs (:): View and edit programs from any screen. Refer to Program Setup, page 10.
- 9- Device Settings (3): View and edit device settings from any screen. Refer to Device Settings, page 11.

Program Setup

Pump Dashboard > All Programs > Program Setup

Programs can be individually set and edited from the All Programs screen, accessed from the Pump Dashboard.

PUMP DASHBOARD SCREEN

- See Running Programs: View and edit all enabled pump programs.
 Opens the See Running Programs screen.
- 2- All Programs Icon (<u></u>): View and edit any enabled or disabled pump program.
 Opens the All Programs screen.

ALL PROGRAMS SCREEN

- 3- Pause/Run Buttons: Tap the Pause Icon (□) to pause a running program.
 Tap the Run Icon (□) to manually start a program.
- 4- Edit Program: Edit or view a particular program.
 Opens the Program Setup screen.
- **5- Scroll Programs:** Scroll through both enabled and disabled programs currently programmed for the pump.

Note: If using the optional Relay Control Board, external control programs will display in the list of programs. Refer to *Relay Control Board Digital Inputs, page* 6 for more information

PROGRAM SETUP SCREEN

- **6- Enable/Disable Program:** Enable or disable the program currently being edited.
- 7- Favorite Program: Add/remove programs to or from your list of favorites. The program will show up in a list of favorite programs accessed via the (♥) icon.
- **8- Nickname:** Set the program nickname. This will be the name the program displays on the All Programs and Pump Dashboard screens.
- **9- Schedule:** Set which days of the week the program will activate the pump.

Note: This option will only appear when editing a Schedule program.

Note: If setting a Timer program, "Schedule" will be replaced by "Timer".


- 10- Pump | Activate: Set the speed or flow that a program will run when activated.
- 11- Mode: Select which type of program you wish to setup.

MANUAL and TIMER programs will not resume after they are overridden by another program or manually stopped by the user.

- Manual: Program will only run, at the set speed or flow, when manually activated.
- Timer: Program will only run, at the set speed or flow and duration, when manually activated.
- Schedule: Program will run on the days and times, and at the speed or flow, that are programmed.
- **12- Start End:** Set the time of day, on the days of the week, that a Schedule program will activate and deactivate the pump.

Note: This option will only appear when editing a Schedule program.

- 13- Relays: Set which relay devices will activate when the program is running.
 - Note: This option will only display if the optional Relay Control Board (P/N 356365z) is installed.
- 14- Save: Save edits made to a program.



Device Settings

Pump Dashboard > Device Settings

Device Settings can be accessed by pressing the Device Settings gear icon (袋) in the bottom-right of the Pump Dashboard.


Tap EDIT to enter any of the menus described below:

- 1- Product Overview: View general information about your pump such as device nickname, address or software version.
- **2- Screen Orientation:** Choose how the screen is displayed.
 - The screen can be shifted to different orientations to best fit a specific install.
- **3- WiFi:** View WiFi network information and signal strength.
- 4- Screen Brightness: View and edit touchscreen brightness.
- **5- Relays:** View and edit your current pump relay device settings.

Refer to Relay Settings, page 12.



- **6- Alert History:** View a list of alerts or faults recorded by the drive.
- **7- Priming Parameters:** View and edit your pump's priming settings. Refer to *Priming Parameters*, page 12.
- **8- Limits Parameters:** View and edit your pump's speed, flow and pressure limits. Refer to *Limits Parameters, page 13*.
- 9- Thermal Mode: View and edit the your pump's Thermal Mode temperature set point and speed/flow settings.
- 10- Automation Configuration: View and edit the pump address associated with your automation system. The pump address entered on this screen must match the address in the automation system. If addresses do not match, the pump can not communicate with an automation system.
- **11- Ramping Speed:** Set how quickly your pump will ramp up or down on startup or when changing speeds/flows. Ramping Speed can be set to FAST, MEDIUM or SLOW.
- 12- Languages: Select the language you wish your touchscreen controller to display.
- 13- Device Security: Set a device lockout pin.
- **14- Date and Time:** Set the current day and time.
- 15- Device Resets: Reset pump settings to their factory defaults. Refer to Default Settings, page 8.



Relay Settings

Pump Dashboard > Device Settings > Relays

The following functionality is only available if the Pentair Relay Control Board (P/N 356365z -- sold separately) has been installed on your pump.


The relay board includes two high-voltage terminals capable of controlling pool lights, salt chlorine generators, booster pumps or other filtration system components. One terminal is intended for 5A max low-current connections and the other for 16A max high-current connections.

Tap EDIT to view and edit your connected devices:

- 1- Device Type: Select the device connected to a particular relay.
 - **RELAY 1 Options:** Lights, Salt Cell or Other
 - RELAY 2 Options: Lights, Salt Cell, Booster Pump or Other

Note: If a relay is designated "Booster Pump", the pump will first ensure the Booster Pump has water by delaying power to the relay until the pump has run for two minutes.

If the pump is already running a program then there will be no delay.



- 2- Device Nickname: Enter the name you want your device to display on Program Setup screens.
- 3- Speed/Flow Dependent: Check this box to ensure the relay is only activated when the pump is running.

Priming Parameters

Pump Dashboard > Device Settings > Priming Parameters

All priming settings can be edited and set from this screen.

Tap EDIT to view and edit the following priming settings:

- 1- Enabled/Disabled: ENABLED allows the pump to detect whether or not the system is properly primed for pump startup.
 - If prime is not detected the pump will enter a priming cycle, based on the settings below.
- **2- Priming Speed:** Set the speed the pump will run during a priming cycle.
- 3- Max Priming Duration: Set the maximum amount of time the pump will attempt to prime. If the pump does not achieve prime during this time a priming error will display and the pump will stop.
- **4– Priming Range:** Set the sensitivity of pump prime detection.
 - Lower settings require higher flow to detect a successful prime.
- **5- Priming Delay:** Set the amount of time the pump remains at priming speed before transitioning to the selected program.
- **6- Loss of Prime:** ENABLED allows the pump to detect low-flow or no-flow situations while running. If a loss of prime is detected the pump will pause and attempt to prime, based on the settings above. If priming is successful the pump will continue programmed operation.



Limits Parameters


Pump Dashboard > Device Settings > Limits Parameters

Set and edit pump speed, flow and pressure limits. These settings will ensure your pump does not operate outside of the programmed parameters.

Tap EDIT to view and edit the following speed, flow and pressure limits:

- 1- Minimum/Maximum Speed: Set the absolute minimum and maximum speeds the pump will be allowed to run. Pump run speed will never run under or over these two settings.
- 2- Minimum/Maximum Flow: Set the absolute minimum and maximum flow rate the pump will be allowed. Pump GPM will never fall under or exceed these two settings.

Note: These minimum and maximum flow rates only apply to Flow Programs. To apply these settings to Speed Programs as well, the next setting (Flow Limit - Speed Programs) must be enabled.




- **3- Flow Limit (Speed Programs):** Enable or disable minimum and maximum flow rate limits for Speed Programs.
- **4- Max Pressure:** Set the maximum system pressure the pump will be allowed to produce. The pump system pressure will never exceed this setting.

Note: The maximum pressure setting only applies to Flow Programs. To apply these settings to Speed Programs as well, the next setting (Pressure Limit - Speed Programs) must be enabled.

5- Pressure Limit (Speed Programs): Enable or disable maximum system pressure limit for Speed Programs.

Touchscreen Menu Tree



MAINTENANCE

Always disconnect power to the pump at the circuit breaker and relieve pressure in the filtration system before servicing the pump. Failure to do so could result in death or serious injury to serviceman, pool users or others due to electric shock. Do NOT attempt to adjust or service without consulting your dealer or a qualified pool technician. Read the entire Installation and Maintenance Guide before attempting to use, service, or adjust the pool filtering system or heater.

Do NOT open the pump strainer pot if pump fails to prime or if pump has been operating without water in the strainer pot. Pumps operated **▲** WARNING in these circumstances may experience a build up of vapor pressure and may contain scalding hot water. Opening the pump may cause serious personal injury. In order to avoid the possibility of personal injury, ensure the suction and return valves are open and strainer pot temperature is cool to touch, then open with extreme caution.

ACAUTION To prevent damage to the pump and for proper operation of the system, clean pump strainer and skimmer baskets regularly.

Cleaning the Pump Strainer Basket

The strainer pot is located at the front of the pump and houses the pump strainer basket.

The strainer basket can be viewed through the strainer pot lid and should be visually inspected at least once a week. Regularly emptying and cleaning the strainer basket will lead to higher filter and heater efficiency and prevent unnecessary stress on the pump motor.

TO CLEAN THE STRAINER BASKET:

- Press ON/STOP to stop the pump and disconnect all power to the pump at the circuit breaker.
- 2. Open the filter's air relief valve and stand clear of the filter until all pressure has been relieved and the pressure gauge reads 0 (zero) psi.
- 3. Turn the strainer pot lid counter-clockwise and remove it from the pump.
- 4. Remove the strainer basket and rinse out all debris. Replace the basket if it is cracked or damaged.
- 5. Place the strainer basket back into the strainer pot. Ensure the opening in the front of the strainer basket is aligned with the suction outlet.
- 6. Fill the strainer pot up to the suction port with water.
- 7. Clean the lid O-ring and sealing surface of the strainer pot.

Note: It is important to keep the lid O-ring clean.

8. Reinstall the lid by placing it onto the strainer pot and tightening clockwise until the lid handles are perpendicular to the suction port.

> **Note:** Ensure the lid O-ring is properly positioned between the lid and strainer pot.

- 9. Open the filter air relief valve and stand clear of the filter.
- 10. Reestablish power to the pump at the circuit breaker and press ON/STOP to start the pump.
- 11. When a steady stream of water flows from the filter air relief valve, close the valve.



THIS SYSTEM OPERATES UNDER HIGH PRESSURE. When any part of the circulating system is serviced, air can enter the system and become pressurized. Pressurized air can cause the lid to separate which can result in serious injury, death, or

property damage. To avoid this potential hazard, follow above instructions.

Winterizing

ACAUTION

Do NOT rely solely on Thermal Mode to protect your filtration system from freezing temperatures.

Thermal Mode is based on the internal drive temperature and may not reflect actual air temperature.


If freezing conditions are expected, take the following steps to reduce the risk of freeze damage. Freeze damage is not covered under warranty.

In mild climate areas, when temporary freezing conditions may occur, run your filtering equipment all night to prevent freezing.

TO PREVENT FREEZE DAMAGE:

- 1. Press ON/STOP to stop the pump and disconnect all power at the circuit breaker.
- 2. Open the filter's air relief valve and stand clear of the filter until all pressure has been relieved and the pressure gauge reads 0 (zero) psi.
- Remove both drain plugs from the bottom of the strainer pot and drain the pump. Store the plugs in the strainer basket.
- 4. Cover the motor to protect it from severe rain, snow and ice.

Note: Do not wrap motor with plastic or other air tight materials during winter storage. Never cover the motor when operating or expecting operation.



SERVICING

Always disconnect power to the pump at the circuit breaker before servicing the pump. Failure to do so could result in death or serious injury to serviceman, pool users or others due to electric shock. Do NOT attempt to adjust or service without consulting your dealer or a qualified pool technician. Read the entire Installation and Maintenance Guide before attempting to use, service, or adjust the pool filtering system or heater.

Do NOT open the pump strainer pot if pump fails to prime or if pump has been operating without water in the strainer pot. Pumps operated in these circumstances may experience a build up of vapor pressure and may contain scalding hot water. Opening the pump may cause serious personal injury. In order to avoid the possibility of personal injury, ensure the suction and return valves are open and strainer pot temperature is cool to touch, then open with extreme caution.



Be sure not to scratch or mar the polished shaft seal faces; seal will leak if faces are damaged. The polished and lapped faces of the seal CAUTION De sure not to soration of not handled with care.

Motor and Drive Care

Protect from heat

- Shade the motor from the sun.
- Any enclosure must be well ventilated to prevent overheating.
- Provide ample cross ventilation.
- Maintain a minimum clearance of 3-inches (7.6 cm) behind the motor fan to allow proper circulation and pump maintenance.

Protect against dirt and chemicals

- Protect from any foreign matter.
- Do not store (or spill) chemicals on or near the motor.
- Avoid sweeping or stirring up dust near the motor while it is operating.
- If a motor has been damaged by dirt it may void the motor warranty.
- Periodically check for debris under the motor shrouds and clean it out. Refer to Disassembly, page 17.

Protect against moisture

- Protect from continuous splashing or continuous sprayed water.
- Protect from extreme weather such as flooding.
- If motor internals have become wet let it dry before operating. Do not allow the pump to operate if it has been flooded.
- If a motor has been damaged by water it may void the motor warranty.
- If the optional drive-mounted touchscreen is installed, ensure the cover is closed when not in use.

Disassembly

TOOLS REQUIRED:

- Socket Wrench and 9/16-inch Socket
- 1/4-inch Hex-head Wrench
- · No. 2 Phillips-head Screwdriver

TO DISASSEMBLE THE PUMP:

- 1. Press ON/STOP to stop the pump and disconnect all power to the pump at the circuit breaker.
- 2. Close all valves in suction and return lines.
- Open the filter's air relief valve and stand clear of the filter until all pressure has been relieved and the pressure gauge reads 0 (zero) psi.
- 4. Remove both Drain Plugs from the Strainer Pot and drain the pump.
- Using a 9/16-inch wrench, remove the six or eight Strainer Pot Bolts securing the Strainer Pot to the Motor/Hydraulic Assembly.
- 6. Gently separate the Motor/Hydraulic Assembly from the Strainer Pot.
- Remove the two or three Phillips-head Diffuser Screws. Remove the Diffuser from the Motor/ Hydraulic assembly.
- 8. At the rear of the motor, insert a 1/4-inch hex-head driver into the hole in the middle of the motor fan cover.
- 9. While holding the motor shaft in place with the 1/4-inch driver, remove the Impeller by rotating it counter-clockwise.
- Loosen the two captive Phillips-head Wiring Cover Screws. Remove the Wiring Cover from the drive.
- Disconnect main power wiring from the drive.
 Note: If the optional Relay Control Board (P/N 356365z) is installed, remove the automation terminal blocks from relay board and disconnect any relay connections.
- 12. Remove the four Phillips-head Drive Cover Screws. Remove the Drive Cover from the drive.
- Remove the four Phillips-head Drive-to-Motor Screws.
- 14. Gently separate the drive from the motor and place it aside.
- 15. Disconnect the bonding wire from the bonding lug.
- 16. Remove two Phillips-head Shroud Screws on each side of the motor and remove both halves of the Motor Shroud from the motor.
- 17. Using a 9/16-inch wrench, remove the four Motor Bolts securing the Seal Plate to the motor.
- 18. Remove the Spring Seal from the motor shaft and place it aside.
- 19. If replacing the Shaft Seal, place the Seal Plate face down and tap out the white Ceramic Seal.

Reassembly

1. If installing a new Shaft Seal:

ACAUTION

Scratching, marring or otherwise damaging the polished shaft seal faces will cause the seal to leak.


Always handle the shaft seal faces with care and clean them thoroughly before reassembling the pump.

- Clean the seal plate's seal cavity and the motor shaft using mild detergent and water.
- b. Lubricate the black rubber portion of the ceramic seal with water.
- c. With the white ceramic face outwards, press the seal into the seal plate with your thumbs.
- 4. Reinstall the seal plate onto the motor.
- 5. Reinstall both halves of the Motor Shroud onto the motor.
- 6. Using a clean cloth, remove any debris from the face of the Ceramic Seal.
- 7. With the flat metal face outwards, place the Spring Seal onto the motor shaft. The carbon face should seat against the Ceramic Seal.
- 8. While holding the motor shaft in place with a 1/4-inch driver, reinstall the impeller onto the motor shaft.
- 9. Reinstall the Diffuser onto the Seal Plate.
- Ensure the gasket is properly seated onto the drive connector and reinstall the drive onto the motor.
- 11. Reconnect the main power and bonding lines to the pump.

Note: If the optional Relay Control Board (P/N 356365z) is used, reinstall the automation terminal blocks onto the relay board and reconnect any relay connections.

- 12. Reinstall the Drive Cover onto the drive.
- 13. Reinstall the Wiring Cover onto the drive.
- 14. Ensure the Diffuser and Seal Plate O-rings are clean and seated properly.
- 15. Reinstall the hydraulic assembly to the Strainer Pot, tightening the bolts in a criss-cross pattern.
- 16. Reinstall the drain plugs into the strainer pot.
- 17. Reprime the pump according to *Priming the Pump*, page 7.

Pump Disassembly/Reassembly Diagram



Drive Removal and Installation

AWARNING To avoid dangerous or fatal electrical shock hazard, switch OFF power to motor before working on pump or motor.

A WARNING

FIRE AND BURN HAZARD. The pump motor may run at high temperatures. To reduce the risk of fire, do NOT allow leaves, debris, or foreign matter to collect around the pump motor. To avoid burns when handling the motor, shut off the motor and allow it to cool for 20 minutes before servicing. The pump provides an automatic internal cutoff switch to protect the motor from heat damage during operation.

▲ CAUTION


To avoid electrical hazard, do NOT remove the four torx-head screws from the drive.

TO DISASSEMBLE AND REMOVE THE DRIVE:

- Press ON/STOP to stop the pump and disconnect all power to the pump at the circuit breaker.
- 2. Loosen the two captive Phillips-head Wiring Cover Screws. Remove the Wiring Cover from the Drive.
- 3. Disconnect main power wiring and remove the Automation Terminal Blocks from the drive.
- 4. Remove the four Phillips-head Drive Cover Screws. Remove the Drive Cover from the Drive.
- 5. Remove the four Phillips-head Drive-to-Motor
- 6. Gently separate the Drive from the Motor/ Hydraulic Assembly and place it aside.

TO INSTALL THE DRIVE:

- 1. Ensure the drive connection gasket is not damaged and is in place.
 - Do not reassemble with a damaged or missing gasket. Replace the gasket if damaged.



- 2. Align the Drive with the Drive Connection and seat the drive onto the motor.
- 3. Secure the Drive to the motor with the four Drive to Motor Screws.
- 4. Reinstall the Drive Cover and secure it with the four Drive Cover Screws.
- 5. Rewire automation and power cables that were disconnected during drive removal. Refer to *Electrical Installation*, page 4 and Connecting to an Automation System, page 5.
- 6. Reinstall the Wiring Cover and secure it with the two Wiring Cover Screws.

Relocating the WiFi Antenna

The pump communicates wirelessly via a Bluetooth® Wireless Technology connection with your personal device, or a 2.4ghz WiFi connection with your home router.

The drive's WiFi antenna features a male SMA bulkhead connector on the outside of the top cover and can be removed by loosening the antenna connector.

An SMA extension cable can be used to remotely mount the antenna in an area where it can receive a better signal.

An extension cable is only recommended in order to relocate the antenna to a more favourable location; such as outside of a masonry enclosure or around the corner of a building. In most other cases using an extension cable will harm the signal.

TROUBLESHOOTING





Always disconnect power to the pump at the circuit breaker and relieve pressure in the filtration system before servicing the pump. Failure to do so could result in death or serious injury to serviceman, pool users or others due to electric shock. Do NOT attempt to adjust or service without consulting your dealer or a qualified pool technician. Read the entire Installation and Maintenance Guide before attempting to use, service, or adjust the pool filtering system or heater.

Drive LED Indicators

Each button on the drive; CONNECT, ON/STOP and QUICK CLEAN features an LED indicator.

Refer to the table to the right for a list of LED behaviors and what they indicate.

= Solid LED

Solid LED

Blinking LED

Pulsing LED

LED	BEHAV	'IOR	INDICATES
	Green	Pulsing	Searching for WiFi connection
	Green	Solid	Active WiFi connection
	Blue	Blinking	Searching for <i>Bluetooth</i> ® connection
CONNECT	Blue	Solid	Active Bluetooth® connection
CONNECT	Yellow	Pulsing	Pump requires provisioning
	reliow	Blinking	Pump update in progress
<u></u>	Manata/Diale	Solid	Automated control is active
	Magenta/Pink	Pulsing	Connected to automation and in service mode
			Pump running
Green		Blinking	Priming cycle
		Pulsing	Pump in Thermal Mode
ON/STOP	Red	Solid	Pump disabled
	Neu	Blinking	Alarm detected
	Green/Yellow Blinkin		Warning detected
	Yellow	Solid	Pump is idle

Troubleshooting Chart

PROBLEM	POSSIBLE CAUSE	CORRECTIVE ACTION	
Connection Issue - Pump is Offline Alert	Pump is not receiving power	Ensure the pump is receiving power. If the pump is receiving power, the ON/STOP button wil illuminate.	
	Home internet service is out or inaccessible	Confirm that the home router is active and connected to the internet.	
	Intermittent WiFi or network connection	Restart the home router. This can clear up many typical home networking issues.	
		Cycle power to the pump. Disconnect power to the pump at the main breaker, Wait for 1 minute and reconnect power.	
		Check the signal strength in WiFi Settings of the Pentair Pool app. If the signal strength is insufficient, refer to the Poor WiFi Signal section of this troubleshooting chart.	
	Bluetooth® connectivity issues	Stand closer to the pump when operating via Bluetooth®.	
		2. Restart the Pentair Pool app.	
		3. Adjust the pump antenna.	
		Ensure smartphone permissions are given to the pump.	

- Troubleshooting Continues on the Next Page -

Troubleshooting Chart (continued)

PROBLEM	POSSIBLE CAUSE	CORRECTIVE ACTION		
Connection Issue - Pump is Offline Alert	Poor WiFi signal to router	The WiFi antenna can be relocated from the top cover of the drive to a location with better WiFi signal. The antenna bulkhead on the cover has a SMA Female connector, and the antenna has a SMA Male connector. A SMA extension cable can be used to move the antenna to a more favorable location such as around the corner of a wall or outside of an enclosure.		
		2. Consider operating the pump in <i>Bluetooth</i> ® Wireless Technology control mode. Refer to the <i>Pentair Pool User's Guide (P/N 356088)</i> for instructions.		
Priming Issue	Air leak in suction	Check suction piping and suction valve seals.		
		Check pool water level and ensure the skimmer is not drawing in air.		
		Check and clean the pump strainer pot lid O-ring.		
	Not enough water in strainer pot	Fill the strainer pot up to the suction port with water.		
	Priming speed or range too low	 Adjust priming parameters/settings (speed, duration, delay, priming range) until the pump consistently primes. If using a touchscreen controller, refer to <i>Priming Parameters</i> on page 12 for instructions. If using the Pentair Pool app, refer to the <i>Pentair Home User's Guide (P/N 356088)</i> for instructions. 		
	Priming alerts	Refer to <i>Alarms and Warnings</i> on page 23 for information regarding specific alarms.		
Reduced Capacity and/or Head	Clogged pump strainer basket	Clean the pump strainer basket. Refer to Cleaning the Pump Strainer Basket on page 15 for instructions.		
	Air pockets or leaks in suction line	Inspect all piping and seals in the suction line.		
	Clogged impeller	Disassemble the pump and remove debris from the impeller. Refer to <i>Disassembly</i> on page 17 and <i>Reassembly</i> on page 17 for instructions.		
	Pump not running required speed	Check the pump drive interface and/or Pentair Pool for alerts or warnings. Refer to <i>Alarms and Warnings</i> on page 23 for information regarding specific alarms.		
Pump Runs then Stops	Over temperature FAULT	Ensure the fan guard is clean. Use compressed air to remover any dirt, debris or blockages.		
	Over current FAULT	Disassemble the pump and check rotating parts for blockages or debris build-up. Clean if necessary. Refer to <i>Disassembly</i> on page 17 and <i>Reassembly</i> on page 17 for instructions. The pump will automatically attempt to restart after 1 minute.		
Pump Increases Speed During Pool Cleaner Operation	Constant FLOW program is running	Schedule a constant SPEED Program to run during expected cleaning cycles.		

⁻ Troubleshooting Continues on the Next Page -

Troubleshooting Chart (continued)

PROBLEM	POSSIBLE CAUSE	CORRECTIVE ACTION	
Pump is Noisy or Operating Loudly	Debris in contact with cooling fan	Ensure the fan guard is clean. Use compressed air to remove any dirt, debris or blockages.	
	Clogged impeller	Disassemble the pump and remove debris from the impeller. Refer to <i>Disassembly</i> on page 17 and <i>Reassembly</i> on page 17 for instructions.	
	Too much debris in strainer basket causing cavitation	Clean the pump strainer basket. Refer to Cleaning the Pump Strainer Basket on page 15 for instructions.	
	Motor speed too high	Consider reducing the speed if possible.	
Pump is Leaking (from Strainer Pot -		Ensure the seal plate O-ring is not pinched between the seal plate and strainer pot.	
Seal Plate Joint)		Tighten the bolts joining the strainer pot and the seal plate.	
		3. If leak persists, disassemble the pump. Inspect all O-rings and seals for damage or debris build-up. Replace or clean the seals if necessary. Refer to <i>Disassembly</i> on page 17 and Reassembly on page 17 for instructions.	
Pump is Leaking (from Strainer Pot Lid)		Ensure the strainer pot lid is installed correctly (lid handles are perpendicular to the suction port) and is compressing the strainer pot lid O-ring.	
		 Refer to Cleaning the Pump Strainer Basket on page 15 and remove the strainer pot lid. Inspect the strainer pot lid O-ring for damage or debris build-up. Replace or clean the O-ring if necessary. 	
Pump is Leaking (from Underneath Motor)		Disassemble the pump and inspect the shaft seal. The shaft seal is a wearable part and will need to be replaced after prolonged operation. Refer to <i>Disassembly</i> on page 17 and <i>Reassembly</i> on page 17 for instructions.	

Alarms and Warnings

When an Alarm is triggered the drive's ON/STOP LED will blink RED and a fault code will display. The pump will stop until the alarm is resolved.


When a Warning is triggered the drive's ON/STOP LED will blink GREEN/YELLOW and a fault coded will display.

Depending on your particular setup, fault codes will display on one or more of the user interfaces:

- Pentair Pool app
- Automation System Interface
- Optional Touchscreen Controller (Almond P/N 356159z, Black P/N 356348z)

ALARM / WARNING	DESCRIPTION	DEFINITION
Weak WiFi Connection	Weak WiFi connection detected.	Pump antenna may be obstructed or too far away from your router. The antenna wire can be extended. Refer to <i>Relocating the WiFi Antenna</i> on page 19.
Offline	The pump is offline.	The Pentair cloud cannot connect to your pump. This could be caused by a power outage at the pump or router, or a loss of WiFi signal to the pump.
Priming Failure	The pump has reported a Priming Failure Alarm.	Priming failure can be caused by lack of water in the volute strainer basket.
Overheat	The pump has reported an Overheat Condition.	The pump motor has detected an abnormally high internal temperature. This can be caused by a blockage of the cooling fan inlet or outlet, or by excessively high ambient air temperature. The pump will attempt to protect itself by reducing the motor speed to give the motor and drive a chance to cool down.
Over Current	The pump has reported an Over Current Condition.	Load has increased on the motor; due to debris, part interference, temperature issues, age of parts, or supplied voltage. Refer to <i>Disassembly</i> on page 17 and inspect the rotating parts of the pump for blockages or debris buildup.
Over Voltage	The pump has reported an Over Voltage Alarm.	Supplied voltage is outside of the proper range. When voltage returns to the normal the alert will clear and the pump will resume operation.
Under Voltage	The pump has reported an Under Voltage Alarm.	Supplied voltage is outside of the proper range. When voltage returns to the normal the alert will clear and the pump will resume operation.
Speed Limit	The pump has reported a Speed Limit Warning.	The pump is operating at the programmed maximum speed in order to achieve the desired speed/flow. Refer to <i>Limits Parameters</i> on page 13 for instructions on adjusting the Speed Limit. If this alert displays and the Speed Limit is already set to 100%, then the pump may not be capable of achieving the desired flow rate.
Pressure Limit	The pump has reported a Pressure Limit Warning.	The pump is operating at the programmed maximum system pressure. The pump monitors Total Dynamic Head, and not outlet pressure, so it may differ from the reading on the filter gauge. Refer to <i>Limits Parameters</i> on page 13 for instructions on adjusting the pump Pressure Limit.
Flow Limit	The pump has reported a Flow Limit Warning.	The pump is operating at the programmed maximum flow rate. Refer to <i>Limits Parameters</i> on page 13 for instructions on adjusting the pump Flow Limit.
Internal Fault	The pump has an internal error.	This alert can be caused by a few different types of internal hardware or software errors in the drive. Disconnect power to the pump and reconnect after one minute. If the alert remains, contact a qualified pool professional.
Drive is Derating (Warning)	The pump is slowing down to prevent the drive from overheating.	This alert usually accompanies an Overheat or Over Current alert. It is intended to note that the pump will continue to operate at a reduced speed as long as possible. After the drive has cooled enough it will automatically resume normal operation.
Derating Alarm - Exceeded & Cut Off	The pump has stopped to prevent the drive from overheating.	The motor and drive are not able to reduce speed enough to protect themselves. The motor will stop and Pentair Pool will display this alarm. When the drive has cooled enough, it will automatically resume operation and attempt to run the requested program.
Thermal Mode	The pump operating in Thermal Mode.	The pump is operating in Thermal mode. Thermal Mode is controlled by the drive's internal temperature, not water temperature. This is intended to keep motor components from freezing, but should not be solely relied on for full filtration system freeze protection.

REPLACEMENT PARTS



Pump Parts List (1.5 HP Models)

Item	Description	Almond Part #	Black Part #	
1	Drive Cover Assembly	356214z	356349z	
2	Field Wiring Compartment Kit	356096Z	06Z 356337z	
3	Blank Controller Kit	356101z	356338z	
4	Touchscreen Controller Kit	356159z	356348z	
5	Touchscreen Lid	356099z	356339z	
6	Relay Control Board Kit	3563	365z	
7	Antenna	3562	226z	
-	4-Pin Connector, RS-485	8023	3304	
9	6-Pin Connector, Relay Control Board	8023	3306	
10	Controller Screw (x4)	3562	215z	
11	Drive and Drive Hardware Kit	3561	62z	
12	Drive Hardware Kit	357	865	
13	7/8" Plug, Drive	3562	219z	
14	1" Bushing, Low Voltage, Drive	3563	320z	
15	Motor Kit	3561	64s	
16	Motor Bracket Kit (x2)	3561	67z	
17	Motor Foot Kit	356149z	356341z	
18	Motor Shroud Kit	357867	357868	
19	Motor Fan Kit	356232z		
20	Bonding Lug	356166z		
21	Motor Foot Screw	356221z		
22	Motor Bolts (x4)	074165z		
23	Seal Plate Kit	356090z 356333		
24	Seal Plate O-ring	356148z		
25	Shaft Seal	356210s		
26	Impeller	356176z		
27	Diffuser	356155z		
28	Diffuser Screws (x3)	356213z		
29	Diffuser O-ring	3561	90z	
30	Strainer Basket	074162z		
31	Lid Assembly	356172z 356368z		
32	Lid O-ring	356189z		
33	Strainer Pot Kit	356174z	356346z	
34	Drain Plug O-ring	1921	115z	
35	Drain Plug	071131z	357161z	
36	Seal Plate-to-Strainer Pot Bolts (x6)	074164z		
-	Seal Kit	357871		
-	Union Kit	351157		
-	Union O-ring	6020018		
-	Riser Plate Kit - Thin (A/B Base)	357833z		
-	Riser Plate Kit - Thick (C Base)	357831z		
-	Riser Plate Kit - Both 357832z			

Pump Parts List (3 HP Models)

Item Description Almond Part # Part # Part # 1 Black part # 356214z 356349z 356349z 356349z 356349z 356396z 356337z 356096z 356337z 356101z 356308z 356338z 356338z 356338z 356338z 356338z 356338z 356338z 356349z 356341z 35786p 357870 356349z 356341z 35786p 357870 356349z 356345z 356349z 3563			A I	Disale
2 Field Wiring Compartment Kit 356096z 356337z 3 Blank Controller Kit 356101z 356338z 4 Touchscreen Controller Kit 356159z 356338z 5 Touchscreen Lid 356099z 356338z 6 Relay Control Board Kit 356099z 356339z 6 Relay Control Board Kit 356226z - 4-Pin Connector, Relay Control Board 8023304 9 6-Pin Connector, Relay Control Board 8023306 10 Controller Screw (x4) 356215z 11 Drive and Drive Hardware Kit 356163z 12 Drive Hardware Kit 356163z 12 Drive Hardware Kit 356163z 13 7/8" Plug, Drive 356219z 14 1" Bushing, Low Voltage, Drive 356219z 15 Motor Kit 356165s 16 Motor Bracket Kit (x2) 356167z 17 Motor Foot Kit 35786e 20 Bonding Lug 35616cz 21 Motor Foot Screw	Item	Description		
3 Blank Controller Kit 356101z 356338z 4 Touchscreen Controller Kit 356159z 356348z 5 Touchscreen Lid 356099z 356339z 6 Relay Control Board Kit 356099z 356339z 6 Relay Control Board Kit 356226z 7 Antenna 356226z - 4-Pin Connector, RS-485 8023304 9 6-Pin Connector, Relay Control Board 8023306 10 Controller Screw (x4) 356215z 11 Drive and Drive Hardware Kit 356163z 12 Drive Hardware Kit 356163z 12 Drive Hardware Kit 356165z 13 7/8" Plug, Drive 356219z 14 1" Bushing, Low Voltage, Drive 356320z 15 Motor Kit 356165s 16 Motor Bracket Kit (x2) 356147z 17 Motor Foot Kit 356149z 20 Bonding Lug 356166z 21 Motor Foot Screw 356221z	1	Drive Cover Assembly	356214z	356349z
4 Touchscreen Controller Kit 356159z 356348z 5 Touchscreen Lid 356099z 356339z 6 Relay Control Board Kit 35639c5z 7 Antenna 356226z - 4-Pin Connector, RS-485 8023304 9 6-Pin Connector, Relay Control Board 8023306 10 Controller Screw (x4) 356215z 11 Drive and Drive Hardware Kit 356163z 12 Drive Hardware Kit 357865 13 7/8" Plug, Drive 356320z 14 1" Bushing, Low Voltage, Drive 356320z 15 Motor Kit 356165z 16 Motor Kit 356149z 356341z 17 Motor Foot Kit 356149z 356341z 18 Motor Foot Kit 356149z 356341z 19 Motor Foot Screw 356221z 20 Bonding Lug 35616z 21 Motor Foot Screw 356221z 22 Motor Foot Screw 356221z <	2	Field Wiring Compartment Kit	356096z	356337z
5 Touchscreen Lid 356099z 356339z 6 Relay Control Board Kit 3563365z 7 Antenna 356226z - 4-Pin Connector, RS-485 802330d 9 6-Pin Connector, Relay Control Board 8023306 10 Controller Screw (x4) 356215z 11 Drive and Drive Hardware Kit 357865 13 7/8" Plug, Drive 356219z 14 1" Bushing, Low Voltage, Drive 356320z 15 Motor Kit 356165s 16 Motor Bracket Kit (x2) 35617z 17 Motor Bracket Kit (x2) 356149z 356341z 18 Motor Shroud Kit 357869 357870 19 Motor Fan Kit 357869 357870 19 Motor Foot Screw 356221z 20 Bonding Lug 356165z 21 Motor Bolts (x4) 074165z 23 Seal Plate Kit 356091z 356345z 24 Seal Plate O-ring 35617z	3	Blank Controller Kit	356101z	356338z
6 Relay Control Board Kit 356365z 7 Antenna 356226z - 4-Pin Connector, RS-485 802330d 9 6-Pin Connector, Relay Control Board 8023306 10 Controller Screw (x4) 356215z 11 Drive and Drive Hardware Kit 356163z 12 Drive Hardware Kit 357865 13 7/8" Plug, Drive 356219z 14 1" Bushing, Low Voltage, Drive 356219z 15 Motor Kit 356165s 16 Motor Bracket Kit (x2) 356167z 17 Motor Foot Kit 357869 357870 18 Motor Foot Kit 357869 357870 19 Motor Fan Kit 357866z 356216cz 20 Bonding Lug 35616cz 35621c 21 Motor Foot Screw 356221z 22 Motor Bolts (x4) 074165z 23 Seal Plate O-ring 356173z 24 Seal Plate O-ring 35617z 25 Sha	4	Touchscreen Controller Kit	356159z	356348z
7 Antenna 356226z - 4-Pin Connector, RS-485 8023304 9 6-Pin Connector, Relay Control Board 8023306 10 Controller Screw (x4) 356215z 11 Drive and Drive Hardware Kit 356163z 12 Drive Hardware Kit 357865 13 7/8" Plug, Drive 356219z 14 1" Bushing, Low Voltage, Drive 356320z 15 Motor Kit 356165s 16 Motor Bracket Kit (x2) 35616z 17 Motor Bracket Kit (x2) 356149z 356341z 18 Motor Foot Kit 357869 357870 19 Motor Fan Kit 357866z 357866z 20 Bonding Lug 356166z 21 Motor Foot Screw 356221z 22 Motor Bolts (x4) 074165z 23 Seal Plate Kit 356091z 356345z 24 Seal Plate O-ring 356173z 25 Shaft Seal 356210s 26 Impeller 35617z 27 Diffuser Screws (x3) 35621	5	Touchscreen Lid	356099z	356339z
- 4-Pin Connector, RS-485 9 6-Pin Connector, Relay Control Board 10 Controller Screw (x4) 11 Drive and Drive Hardware Kit 12 Drive Hardware Kit 1357865 13 7/8" Plug, Drive 14 1" Bushing, Low Voltage, Drive 15 Motor Kit 16 Motor Bracket Kit (x2) 17 Motor Foot Kit 18 Motor Shroud Kit 19 Motor Fan Kit 20 Bonding Lug 21 Motor Foot Screw 22 Motor Bolts (x4) 23 Seal Plate Kit 24 Seal Plate O-ring 25 Shaft Seal 26 Diffuser O-ring 30 Strainer Basket 30 Brainer Pot Kit 31 Seal Plate - Seal Kit 32 Seal Plate - O-ring 33 Strainer Pot Kit 356172 3563472 3563472 36 Seal Plate - O-ring 3561722 30 Strainer Pot Kit 3563452 3563452 3563452 3563632 3563682 3563772 3563682 3563772 3563682 3563772 3563682 3563772 3563682 3563772 3563682 35772 3571312 3571612 36 Seal Plate-to-Strainer Pot Bolts (x8) 357872 - Seal Kit 410029 - Union O-ring - Diamond Seal	6	Relay Control Board Kit	356365z	
9 6-Pin Connector, Relay Control Board 10 Controller Screw (x4) 356215z 11 Drive and Drive Hardware Kit 356163z 12 Drive Hardware Kit 357865 13 7/8" Plug, Drive 35632∪z 14 1" Bushing, Low Voltage, Drive 35632∪z 15 Motor Kit 356165s 16 Motor Bracket Kit (x2) 356157z 17 Motor Foot Kit 356149z 356341z 18 Motor Shroud Kit 357869 357870 19 Motor Fan Kit 357866z 20 Bonding Lug 356116c 21 Motor Foot Screw 356221z 22 Motor Bolts (x4) 074165z 23 Seal Plate Kit 356091z 356345z 24 Seal Plate O-ring 356173z 25 Shaft Seal 356210s 26 Impeller 356177z 27 Diffuser 356156c 28 Diffuser Screws (x3) 356213z 29 Diffuser O-ring 356190z 30 Strainer Basket 400007z 31 Lid Assembly 356172z 356368z 32 Lid O-ring 356175z 356368z 33 Strainer Pot Kit 356175z 356347z 34 Drain Plug O-ring 192115z 35 Drain Plug 071131z 357161z 36 Seal Plate-to-Strainer Pot Bolts (x8) 074164z - Seal Kit 357872 - 2" / 2.5" Union Kit 410029 - Union O-ring - Diamond Seal 410016z	7	Antenna	356226z	
10 Controller Screw (x4) 356215z 11 Drive and Drive Hardware Kit 357865 12 Drive Hardware Kit 357865 13 7/8" Plug, Drive 356219z 14 1" Bushing, Low Voltage, Drive 356320z 15 Motor Kit 356165s 16 Motor Bracket Kit (x2) 356167z 17 Motor Foot Kit 356149z 356341z 18 Motor Shroud Kit 357869 357870 19 Motor Fan Kit 357866z 20 Bonding Lug 356166z 21 Motor Foot Screw 356221z 22 Motor Bolts (x4) 074165z 23 Seal Plate Kit 356091z 356345z 24 Seal Plate Kit 356091z 356345z 25 Shaft Seal 356210s 26 Impeller 356177z 27 Diffuser Oring 356156z 28 Diffuser Screws (x3) 356213z 29 Diffuser Oring 356190z 30 Strainer Basket 400007z 31 Lid Assembly 356172z 356368z 32 Lid Oring 356175z 356347z 34 Drain Plug Oring 192115z 35 Drain Plug Oring 192115z 36 Seal Plate-to-Strainer Pot Bolts (x8) 074164z Seal Kit 357872 - 2" / 2.5" Union Kit 410029 - Union O-ring - Diamond Seal 410016z	-	4-Pin Connector, RS-485	8023304	
11 Drive and Drive Hardware Kit 357865 12 Drive Hardware Kit 357865 13 7/8" Plug, Drive 356320z 14 1" Bushing, Low Voltage, Drive 356320z 15 Motor Kit 356165s 16 Motor Bracket Kit (x2) 356167z 17 Motor Foot Kit 356149z 356341z 18 Motor Shroud Kit 357869 357870 19 Motor Fan Kit 357866z 20 Bonding Lug 356166z 21 Motor Foot Screw 356221z 22 Motor Bolts (x4) 074165z 23 Seal Plate Kit 356091z 356345z 24 Seal Plate O-ring 356173z 25 Shaft Seal 356210s 26 Impeller 356177z 27 Diffuser 356156z 28 Diffuser Screws (x3) 356213z 29 Diffuser O-ring 356170z 30 Strainer Basket 400007z 31 Lid Assembly 356172z 356368z 32 Lid O-ring 356175z 3563647z 31 Lid Assembly 356175z 3563647z 32 Drain Plug O-ring 192115z 35 Drain Plug O-ring 192115z 36 Seal Plate-to-Strainer Pot Bolts (x8) 074164z - Seal Kit 357872 - 2" / 2.5" Union Kit 410028 - Union O-ring - Diamond Seal 410016z	9	6-Pin Connector, Relay Control Board	8023306	
12 Drive Hardware Kit 357865 13 7/8" Plug, Drive 356219z 14 1" Bushing, Low Voltage, Drive 356320z 15 Motor Kit 356165s 16 Motor Bracket Kit (x2) 356167z 17 Motor Foot Kit 356149z 356341z 18 Motor Shroud Kit 357869 357870 19 Motor Fan Kit 357866z 20 Bonding Lug 356166z 21 Motor Foot Screw 356221z 22 Motor Bolts (x4) 074165z 23 Seal Plate Kit 356091z 356345z 24 Seal Plate O-ring 356173z 25 Shaft Seal 356210s 26 Impeller 356177z 27 Diffuser O-ring 356190z 30 Strainer Basket 400007z 31 Lid Assembly 356175z 356368z 32 Lid O-ring 356175z 3563647z 34 Drain Plug O-ring 192115z 35 Drain Plug O-ring 071131z 357161z<	10	Controller Screw (x4)	3562	215z
13 7/8" Plug, Drive 356219z 14 1" Bushing, Low Voltage, Drive 356320z 15 Motor Kit 356165s 16 Motor Bracket Kit (x2) 356167z 17 Motor Foot Kit 356149z 356341z 18 Motor Shroud Kit 357869 357870 19 Motor Fan Kit 357866z 20 Bonding Lug 356166z 21 Motor Foot Screw 356221z 22 Motor Bolts (x4) 074165z 23 Seal Plate Kit 356091z 356345z 24 Seal Plate O-ring 356173z 25 Shaft Seal 356177z 27 Diffuser 356156z 28 Diffuser Screws (x3) 356190z 30 Strainer Basket 400007z 31 Lid Assembly 356172z 356368z 32 Lid O-ring 356172z 356368z 33 Strainer Pot Kit 356175z 356347z 34 Drain Plug O-ring 192115z 35 Drain Plug O-ring 19211	11	Drive and Drive Hardware Kit	356163z	
14 1" Bushing, Low Voltage, Drive 356320z 15 Motor Kit 356165s 16 Motor Bracket Kit (x2) 356167z 17 Motor Foot Kit 356149z 356341z 18 Motor Shroud Kit 357869 357870 19 Motor Fan Kit 357866z 20 Bonding Lug 356166z 21 Motor Foot Screw 356221z 22 Motor Bolts (x4) 074165z 23 Seal Plate Kit 356091z 356345z 24 Seal Plate O-ring 356173z 25 Shaft Seal 356210s 26 Impeller 356177z 27 Diffuser 356156z 28 Diffuser O-ring 356190z 30 Strainer Basket 400007z 31 Lid Assembly 356172z 356368z 32 Lid O-ring 356175z 356368z 33 Strainer Pot Kit 356175z 356347z 34 Drain Plug O-ring 192115z 35 Drain Plug O-ring 192115z <	12	Drive Hardware Kit	357865	
15 Motor Bracket Kit (x2) 356165s 16 Motor Bracket Kit (x2) 356147z 17 Motor Foot Kit 356149z 356341z 18 Motor Shroud Kit 357869 357870 19 Motor Fan Kit 357866z 20 Bonding Lug 356166z 21 Motor Foot Screw 356221z 22 Motor Bolts (x4) 074165z 23 Seal Plate Kit 356091z 356345z 24 Seal Plate O-ring 356173z 356345z 24 Seal Plate O-ring 356177z 356177z 27 Diffuser 356177z 356156z 28 Diffuser Screws (x3) 356213z 29 Diffuser O-ring 356190z 30 Strainer Basket 400007z 31 Lid Assembly 356172z 356368z 32 Lid O-ring 356175z 356364z 34 Drain Plug O-ring 192115z 35 Drain Plug O-ring 192115z <	13	7/8" Plug, Drive	356219z	
16 Motor Bracket Kit (x2) 356147z 17 Motor Foot Kit 356149z 356341z 18 Motor Shroud Kit 357869 357870 19 Motor Fan Kit 357866z 20 Bonding Lug 356166z 21 Motor Foot Screw 356221z 22 Motor Bolts (x4) 074165z 23 Seal Plate Kit 356091z 356345z 24 Seal Plate O-ring 356173z 25 Shaft Seal 356210s 26 Impeller 35617z 27 Diffuser 356156z 28 Diffuser Screws (x3) 356213z 29 Diffuser O-ring 356190z 30 Strainer Basket 400007z 31 Lid Assembly 356172z 356368z 32 Lid O-ring 356175z 356368z 33 Strainer Pot Kit 356175z 3563647z 34 Drain Plug O-ring 192115z 35 Drain Plug 071131z 357161z 36 Seal Plate-to-Strainer Pot Bolts (x8)	14	1" Bushing, Low Voltage, Drive	356320z	
17 Motor Foot Kit 356149z 356341z 18 Motor Shroud Kit 357869 357870 19 Motor Fan Kit 357866z 20 Bonding Lug 356166z 21 Motor Foot Screw 356221z 22 Motor Bolts (x4) 074165z 23 Seal Plate Kit 356091z 356345z 24 Seal Plate O-ring 356173z 25 Shaft Seal 356210s 26 Impeller 356177z 27 Diffuser 356156z 28 Diffuser Screws (x3) 356213z 29 Diffuser O-ring 356190z 30 Strainer Basket 400007z 31 Lid Assembly 356172z 356368z 32 Lid O-ring 356175z 3563647z 34 Drain Plug O-ring 192115z 35 Drain Plug 071131z 357161z 36 Seal Plate-to-Strainer Pot Bolts (x8) 074164z - Seal Kit 357872 - 2" / 2.5" Union Kit 410028 <td>15</td> <td>Motor Kit</td> <td colspan="2">356165s</td>	15	Motor Kit	356165s	
18 Motor Shroud Kit 357869 357870 19 Motor Fan Kit 357866z 20 Bonding Lug 356166z 21 Motor Foot Screw 356221z 22 Motor Bolts (x4) 074165z 23 Seal Plate Kit 356091z 356345z 24 Seal Plate O-ring 356173z 25 Shaft Seal 356210s 26 Impeller 356177z 27 Diffuser 356156z 28 Diffuser Screws (x3) 356213z 29 Diffuser O-ring 356190z 30 Strainer Basket 400007z 31 Lid Assembly 356172z 356368z 32 Lid O-ring 356175z 356368z 33 Strainer Pot Kit 356175z 356347z 34 Drain Plug O-ring 192115z 35 Drain Plug 071131z 357161z 36 Seal Plate-to-Strainer Pot Bolts (x8) 074164z - Seal Kit 357872 - 2" / 2.5" Union Kit 410028 <td>16</td> <td>Motor Bracket Kit (x2)</td> <td colspan="2">356167z</td>	16	Motor Bracket Kit (x2)	356167z	
19 Motor Fan Kit 357866z 20 Bonding Lug 356166z 21 Motor Foot Screw 3562∠1z 22 Motor Bolts (x4) 074165z 23 Seal Plate Kit 356091z 356345z 24 Seal Plate O-ring 356173z 25 Shaft Seal 3562∠10s 26 Impeller 356177z 27 Diffuser 356156z 28 Diffuser Screws (x3) 3562√13z 29 Diffuser O-ring 356190z 30 Strainer Basket 400007z 31 Lid Assembly 356172z 356368z 32 Lid O-ring 356175z 356347z 34 Drain Plug O-ring 192115z 35 Drain Plug 071131z 357161z 36 Seal Plate-to-Strainer Pot Bolts (x8) 074164z - Seal Kit 357872 - 2" / 2.5" Union Kit 410029 - Union O-ring - Diamond Seal 410016z	17	Motor Foot Kit	356149z	356341z
20 Bonding Lug 356166z 21 Motor Foot Screw 356221z 22 Motor Bolts (x4) 074165z 23 Seal Plate Kit 356091z 356345z 24 Seal Plate O-ring 356173z 25 Shaft Seal 35617z 26 Impeller 35617z 27 Diffuser 356156z 28 Diffuser Screws (x3) 356213z 29 Diffuser O-ring 356190z 30 Strainer Basket 400007z 31 Lid Assembly 356172z 356368z 32 Lid O-ring 356189z 33 Strainer Pot Kit 356175z 356347z 34 Drain Plug O-ring 192115z 35 Drain Plug O-ring 192115z 35 Drain Plug 071131z 357161z 36 Seal Plate-to-Strainer Pot Bolts (x8) 074164z - Seal Kit 35787z - 2" / 2.5" Union Kit 410028 - 3" Union Cring - Diamond Seal 410016z	18	Motor Shroud Kit	357869	357870
21 Motor Foot Screw 356221z 22 Motor Bolts (x4) 074165z 23 Seal Plate Kit 356091z 356345z 24 Seal Plate O-ring 356173z 25 Shaft Seal 356210s 26 Impeller 356177z 27 Diffuser 356156z 28 Diffuser Screws (x3) 356213z 29 Diffuser O-ring 356190z 30 Strainer Basket 400007z 31 Lid Assembly 356172z 356368z 32 Lid O-ring 356189z 33 Strainer Pot Kit 356175z 356347z 34 Drain Plug O-ring 192115z 35 Drain Plug 071131z 357161z 36 Seal Plate-to-Strainer Pot Bolts (x8) 074164z - Seal Kit 357872 - 2" / 2.5" Union Kit 410028 - 3" Union Cring - Diamond Seal 410016z	19	Motor Fan Kit	357866z	
22 Motor Bolts (x4) 074165z 23 Seal Plate Kit 356091z 356345z 24 Seal Plate O-ring 356173z 25 Shaft Seal 356210s 26 Impeller 356177z 27 Diffuser 356156z 28 Diffuser Screws (x3) 356213z 29 Diffuser O-ring 356190z 30 Strainer Basket 400007z 31 Lid Assembly 356172z 356368z 32 Lid O-ring 356175z 356347z 33 Strainer Pot Kit 356175z 356347z 34 Drain Plug O-ring 192115z 35 Drain Plug 071131z 357161z 36 Seal Plate-to-Strainer Pot Bolts (x8) 074164z - Seal Kit 357872 - 2" / 2.5" Union Kit 410028 - Union O-ring - Diamond Seal 410016z	20	Bonding Lug	356166z	
23 Seal Plate Kit 356091z 356345z 24 Seal Plate O-ring 356173z 25 Shaft Seal 356210s 26 Impeller 356177z 27 Diffuser 356156z 28 Diffuser Screws (x3) 356213z 29 Diffuser O-ring 356190z 30 Strainer Basket 400007z 31 Lid Assembly 356172z 356368z 32 Lid O-ring 356175z 356368z 33 Strainer Pot Kit 356175z 356347z 34 Drain Plug O-ring 192115z 35 Drain Plug 071131z 357161z 36 Seal Plate-to-Strainer Pot Bolts (x8) 074164z - Seal Kit 357872 - 2" / 2.5" Union Kit 410028 - 3" Union Kit 410029 - Union O-ring - Diamond Seal 410016z	21	Motor Foot Screw	356221z	
24 Seal Plate O-ring 356173z 25 Shaft Seal 356210s 26 Impeller 356177z 27 Diffuser 356156z 28 Diffuser Screws (x3) 356213z 29 Diffuser O-ring 356190z 30 Strainer Basket 400007z 31 Lid Assembly 356172z 356368z 32 Lid O-ring 356175z 356347z 33 Strainer Pot Kit 356175z 356347z 34 Drain Plug O-ring 192115z 35 Drain Plug 071131z 357161z 36 Seal Plate-to-Strainer Pot Bolts (x8) 074164z - Seal Kit 357872 - 2" / 2.5" Union Kit 410028 - 3" Union Kit 410029 - Union O-ring - Diamond Seal 410016z	22	Motor Bolts (x4)	0741	165z
25 Shaft Seal 356210s 26 Impeller 356177z 27 Diffuser 356156z 28 Diffuser Screws (x3) 356213z 29 Diffuser O-ring 356190z 30 Strainer Basket 400007z 31 Lid Assembly 356172z 356368z 32 Lid O-ring 356175z 356347z 33 Strainer Pot Kit 356175z 356347z 34 Drain Plug O-ring 19215z 35 Drain Plug 071131z 357161z 36 Seal Plate-to-Strainer Pot Bolts (x8) 074164z - Seal Kit 357872 - 2" / 2.5" Union Kit 410028 - 3" Union Kit 410029 - Union O-ring - Diamond Seal 410016z	23	Seal Plate Kit	356091z	356345z
26 Impeller 356177z 27 Diffuser 356156z 28 Diffuser Screws (x3) 356213z 29 Diffuser O-ring 356190z 30 Strainer Basket 400007z 31 Lid Assembly 356172z 356368z 32 Lid O-ring 356189z 33 Strainer Pot Kit 356175z 356347z 34 Drain Plug O-ring 192115z 35 Drain Plug 071131z 357161z 36 Seal Plate-to-Strainer Pot Bolts (x8) 074164z - Seal Kit 357872 - 2" / 2.5" Union Kit 410028 - 3" Union Kit 410029 - Union O-ring - Diamond Seal 410016z	24	Seal Plate O-ring	3561	173z
27 Diffuser 356156z 28 Diffuser Screws (x3) 356213z 29 Diffuser O-ring 356190z 30 Strainer Basket 400007z 31 Lid Assembly 356172z 356368z 32 Lid O-ring 356189z 33 Strainer Pot Kit 356175z 356347z 34 Drain Plug O-ring 192115z 35 Drain Plug 071131z 357161z 36 Seal Plate-to-Strainer Pot Bolts (x8) 074164z - Seal Kit 357872 - 2" / 2.5" Union Kit 410028 - 3" Union Kit 410029 - Union O-ring - Diamond Seal 410016z	25	Shaft Seal	3562	210s
28 Diffuser Screws (x3) 356213z 29 Diffuser O-ring 356190z 30 Strainer Basket 400007z 31 Lid Assembly 356172z 356368z 32 Lid O-ring 356189z 33 Strainer Pot Kit 356175z 356347z 34 Drain Plug O-ring 192115z 35 Drain Plug 071131z 357161z 36 Seal Plate-to-Strainer Pot Bolts (x8) 074164z - Seal Kit 357872 - 2" / 2.5" Union Kit 410028 - 3" Union Kit 410029 - Union O-ring - Diamond Seal 410016z	26	Impeller	3561	177z
29 Diffuser O-ring 356190z 30 Strainer Basket 400007z 31 Lid Assembly 356172z 356368z 32 Lid O-ring 356189z 33 Strainer Pot Kit 356175z 356347z 34 Drain Plug O-ring 192115z 35 Drain Plug 071131z 357161z 36 Seal Plate-to-Strainer Pot Bolts (x8) 074164z - Seal Kit 357872 - 2" / 2.5" Union Kit 410028 - 3" Union Kit 410029 - Union O-ring - Diamond Seal 410016z	27	Diffuser	356156z	
30 Strainer Basket 400007z 31 Lid Assembly 356172z 356368z 32 Lid O-ring 356189z 33 Strainer Pot Kit 356175z 356347z 34 Drain Plug O-ring 192115z 35 Drain Plug 071131z 357161z 36 Seal Plate-to-Strainer Pot Bolts (x8) 074164z - Seal Kit 357872 - 2" / 2.5" Union Kit 410028 - Union O-ring - Diamond Seal 410016z	28	Diffuser Screws (x3)	356213z	
31 Lid Assembly 356172z 356368z 32 Lid O-ring 356189z 33 Strainer Pot Kit 356175z 356347z 34 Drain Plug O-ring 192115z 35 Drain Plug 071131z 357161z 36 Seal Plate-to-Strainer Pot Bolts (x8) 074164z - Seal Kit 357872 - 2" / 2.5" Union Kit 410028 - 3" Union Kit 410029 - Union O-ring - Diamond Seal 410016z	29	Diffuser O-ring	356190z	
32 Lid O-ring 356189z 33 Strainer Pot Kit 356175z 356347z 34 Drain Plug O-ring 192115z 35 Drain Plug 071131z 357161z 36 Seal Plate-to-Strainer Pot Bolts (x8) 074164z - Seal Kit 357872 - 2" / 2.5" Union Kit 410028 - 3" Union Kit 410029 - Union O-ring - Diamond Seal 410016z	30	Strainer Basket	400007z	
33 Strainer Pot Kit 356175z 356347z 34 Drain Plug O-ring 192115z 35 Drain Plug 071131z 357161z 36 Seal Plate-to-Strainer Pot Bolts (x8) 074164z - Seal Kit 357872 - 2" / 2.5" Union Kit 410028 - 3" Union Kit 410029 - Union O-ring - Diamond Seal 410016z	31	Lid Assembly	356172z	356368z
34 Drain Plug O-ring 192115z 35 Drain Plug 071131z 357161z 36 Seal Plate-to-Strainer Pot Bolts (x8) 074164z - Seal Kit 357872 - 2" / 2.5" Union Kit 410028 - 3" Union Kit 410029 - Union O-ring - Diamond Seal 410016z	32	Lid O-ring	3561	189z
35 Drain Plug 071131z 357161z 36 Seal Plate-to-Strainer Pot Bolts (x8) 074164z - Seal Kit 357872 - 2" / 2.5" Union Kit 410028 - 3" Union Kit 410029 - Union O-ring - Diamond Seal 410016z	33	Strainer Pot Kit	356175z	356347z
36 Seal Plate-to-Strainer Pot Bolts (x8) 074164z - Seal Kit 357872 - 2" / 2.5" Union Kit 410028 - 3" Union Kit 410029 - Union O-ring - Diamond Seal 410016z	34	Drain Plug O-ring	1921	115z
- Seal Kit 357872 - 2" / 2.5" Union Kit 410028 - 3" Union Kit 410029 - Union O-ring - Diamond Seal 410016z	35	Drain Plug	071131z	357161z
- 2" / 2.5" Union Kit 410028 - 3" Union Kit 410029 - Union O-ring - Diamond Seal 410016z	36	Seal Plate-to-Strainer Pot Bolts (x8)	074164z	
- 3" Union Kit 410029 - Union O-ring - Diamond Seal 410016z	-	Seal Kit	357872	
- Union O-ring - Diamond Seal 410016z	-	2" / 2.5" Union Kit	410028	
	-	3" Union Kit	410029	
	-	Union O-ring - Diamond Seal	410016z	
- Riser Plate Kit - Thin (A/B Base) 357833z	-	Riser Plate Kit - Thin (A/B Base) 357833z		333z


TECHNICAL DATA


Technical Specifications (1.5 HP Models)


Input Voltage Nominal	115/208-230 VAC
Input Current	12.0/6.4-5.9 Amps
Input Frequency	1PH, L1-L2 or L-N, 50 or 60 Hz
Max Input Watts	1350 W
Max Shaft Horsepower	1.5 HP
Speed Range	400 - 4000 RPM

Environmental Enclosure Rating	NEMA Type 3 / IPX5	
Ambient Condition Range		
Storage	-40°C to +60°C (-40°F to 140°F)	
Operating	0-50°C (32-122°F)	
Humidity	Relative 0-95% Non-Condensing	


Pump Dimensions (1.5 HP Models)







Pump Performance Curves (1.5 HP Models)





Technical Specifications (3 HP Models)


Input Voltage Nominal	208-230 VAC
Input Current	12.4/11.2 Amps
Input Frequency	1PH, L1-L2 or L-N, 50 or 60 Hz
Max Input Watts	2590 W
Max Shaft Horsepower	3.0 HP
Speed Range	450 - 3450 RPM

Environmental Enclosure Rating	NEMA Type 3 / IPX5	
Ambient Condition Range		
Storage	-40°C to +60°C (-40°F to 140°F)	
Operating	0-50°C (32-122°F)	
Humidity	Relative 0-95% Non-Condensing	


Pump Dimensions (3 HP Models)







Pump Performance Curves (3 HP Models)





1620 HAWKINS AVE., SANFORD, NC 27330 • (919) 566-8000 10951 WEST LOS ANGELES AVE., MOORPARK, CA 93021 • (805) 553-5000

All indicated Pentair trademarks and logos are property of Pentair. Third party registered and unregistered trademarks and logos are the property of their respective owners. The *Bluetooth®* word mark and logo are registered trademarks of Bluetooth SIG, Inc. in the United States and/or other countries.

© 2025 Pentair. All rights reserved. WWW.PENTAIR.COM



P/N 356231 REV. E 6/30/25